OPERATING INSTRUCTIONS



Manufacturer: Jonard Tools®

Product Name:

Jonard Tools® MDC-64 Large Fiber Optic Duct Cutter (Up to 64 mm)

Manufacturer Part Number:

MDC-64

Click here for more details on the Jonard Tools® MDC-64 Large Fiber Optic Duct Cutter (Up to 64 mm)

MDC-64 Blade Replacement Instructions

1. Remove the hook on the lower part of the handle



2. Unscrew the 2 screws of the rigid handle and remove the grip



Contact the professionals at Fiber Optic Center for a quote or to get more details.

3. Remove the 5 screws holding the housing together, and remove the faceplate



4. While the faceplate is open, remove the dull blade




Contact the professionals at Fiber Optic Center for a quote or to get more details.

5. Position the moveable handle so that the pin is situated, and the lever is contacting the spring



6. While holding the moveable handle in place, put the new blade into the housing



7. Position the torsion spring so that it is contacting the flat part of the back of the blade



8. Fit the faceplate back onto the unit it snaps into place and replace the assembly.



Contact the professionals at Fiber Optic Center for a quote or to get more details.